# INSTALLATION INSTRUCTIONS

For Model #1005-44-PL

**WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.**

**CAUTION**

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

**GENERAL**

All electrical connections must be in accordance with local and national electrical code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instruction.

**ASSEMBLY AND INSTALLATION**

1. Turn off the power.
2. Pull the Supply Wires (3)&(4) and House Ground Wire(2) out from the Outlet Box(1)
3. Install the Canopy(11)to the Outlet Box(1)by using two Mounting Screws(13)(Note: The side of the Canopy marked"GND" must face out)
4. Position your fixture over the Outlet box (1). Mark the location of the four Slot Holes(14) located on the fixture body. Remove the fixture body from the ceiling. Drill the four holes(9)using the appropriately sized drill bit. Insert the provided ceiling anchors(10) into the holes.
5. Make the wiring connections: Connect the House Ground Wire (2) to the Fixture Ground Wire(8); connect the White Supply Wire (3) to the White Fixture Wire (7); connect Black Supply Wire (4) to the Black Fixture Wire (5) using Wire Connectors(6). Carefully tuck all wires back into the Outlet Box.(See Fig.3)
6. Attach the Fixture Pan(22)to the Canopy(11)through the two Downward Screws(12)and tight it with two Nuts(15)
7. Feed the four Anchor Screws (16) through the Slot Holes. Tighten the Anchor Screws into the Ceiling Anchors until the Fixture Body is flush with the ceiling.
8. Install the tube (18). Please follow the wattage label located on the fixture body. Do not exceed the recommend wattage.
9. Follow drawing #2 to install the Acrylic Lens (19). Hook the Clips(21) of the lens to the curve edge of the Fixture Pan (22 ). (see Figure 2 )

**INSTALLATION IS NOW COMPLETED**

Fig 1




Fig 2




| | |
|---|---|
| 1.OUTLET BOX | 12.DOWNWARD SCREW |
| 2.HOUSE GROUND WIRE | 13.MOUNTING SCREW |
| 3.WHITE SUPPLY WIRE | 14.SLOT HOLES |
| 4.BLACK SUPPLY WIRE | 15.NUTS |
| 5.BLACK FIXTURE WIRE | 16.ANCHOR SCREWS |
| 6.WIRE CONNECTORS | 17.WIRE COVER |
| 7.WHITE FIXTURE WIRE | 18.TUBE |
| 8.FIXTURE GROUND WIRE | 19.ACRYLIC LENS |
| 9.DRILLED HOLES | 20.SCREW |
| 10.ANCHORS | 21.CLIPS |
| 11.CANOPY | 22. FIXTURE PAN |

**Fig.3**


FIXTURE WIRES Black or Smooth
HOUSE WIRES Black (Hot)
FIXTURE WIRES White or Ribbed
HOUSE WIRES White (Neutral)
FIXTURE WIRES Bare Copper (Ground)
HOUSE WIRES Green (Ground)

UL Listed

american lighting association

PDF created with pdfFactory Pro trial version www.pdffactory.com